

Silverline Handset Guide



Think Tank, Ruston Way,
Lincoln, LN6 7FL

01522 717750

www.bluecubetele.com

Cold Transfer (put a call straight through to the intended party):

Whilst on the call, press 'TRAN'

Dial the extension number

Press 'TRAN' again to transfer the call

Warm Transfer (speak to the intended party before you transfer the call):

Whilst on the call, press 'TRAN'

Dial the extension number

Press # (this puts the original call on hold whilst you speak to the intended party)

Press 'TRAN' again to transfer the call

Pick-Up a call:

Dial *98# (this will pick up the FIRST call in the group – this can be an external DDI call, internal transfer or internal call)

Conference call:

Dial the first number

Place the caller on 'HOLD'

Select 'NEW CALL' and dial the second number

Press 'CONF' and both calls will merge

Call forwards:

This function is easiest through the Unity PC Client

- Settings Tab > Services > Call Forward Always (Forwards ALL calls to another number/ extension)
- Settings Tab > Services > Call Forward Busy (Forwards calls to another number/ extension when you are on a call)
- Settings Tab > Services > Call Forward No Answer (Forwards calls to another number/ extension if the call isn't answered in a certain amount of rings)